


JØTUL F 171 Zensoric JØTUL F 174 Zensoric JØTUL F 176 Zensoric

OPERATING INSTRUCTIONS



Manual version P00
EN 16510
Jøtul AS, June 2025

Jøtul AS,
P.o. box 1411
N-1602 Fredrikstad,
Norway
intl.jotul.com



Before installing the product, you must check whether the stove can be used with a balanced chimney. To do this, see page 10.

CONTENTS

TECHNICAL DATA	4
SAFETY	8
FIRE PREVENTION MEASURES	8
GLOVE	8
FLOOR	8
WALLS	8
CEILING	8
BALANCED DRAFT CHIMNEY COMPATABILITY ..	10
INLET FOR BALANCED CHIMNEY	10
DIMENSIONS.....	11
MINIMUM DISTANCES.....	12
INSTALLATION.....	13
CHIMNEY AND FLUE PIPE.....	14
FRESH AIR INTAKE	15
CLOSED COMBUSTION SYSTEM	15
EXISTING CHIMNEY AND PRE-FABRICATED ELEMENT CHIMNEY	15
CONNECTION BETWEEN STOVE AND STEEL CHIMNEY	15
REMOVAL OF PACKAGING	16
REMOVAL OF TRANSPORT PROTECTION.....	18
ZENSORIC SETTINGS	19
BATTERY CHARGING	19
HEIGHT ADJUSTMENT OF WOOD STOVE	20
DOOR (SELF CLOSING)	21
CLOSING THE DOOR.....	21
SMOKE OUTLET REAR EXIT	22
JØTUL F 176 ZENSORIC (HIGH TOP) ASSEMBLY	25
HEAT ACCUMULATING STONE (ACCESSORIES) ..	26
FLOOR PLATE (ACCESSORIES)	27
INSTRUCTION FOR USE	28
CB-TECHNOLOGY (CLEAN BURN)	28
ELECTRONIC AIR CONTROL.....	28
MANUAL AIR CONTROL.....	28
BAFFLE PLATES	28
ASH CONTAINER	28
DAILY USE	30

ODOURS WHEN USING THE FIREPLACE FOR THE FIRST TIME.....	30
“TOP DOWN” LIGHTING THE FIRE	30
ADDING FIREWOOD.....	30
HEATING ADVICE	31
WARNING AGAINST OVERHEATING	31
REMOVING ASH.....	31
OPERATION UNDER DIFFERENT WEATHER CONDITIONS	31
CONDENSATION	32
THE CHIMNEY’S FUNCTION	32
GENERAL NOTES.....	32

MAINTENANCE

CLEANING THE GLASS	33
CLEANING AND REMOVING SOOT	33
SWEEPING THE FLUE PIPE TO THE CHIMNEY ...	34
CHECKING THE FIREPLACE.....	34
EXTERNAL MAINTENANCE	34
SIDE PANEL DISASSEMBLY	35
SIDE PANEL ASSEMBLY	40
ENABLE SELF-CLOSING DOOR	44
DISASSEMBLY TEMPERATURE GAUGE	44
ASSEMBLY TEMPERATURE GAUGE	45
DISASSEMBLY DOOR SENSOR.....	46
ASSEMBLY DOOR SENSOR	47
REMOVAL OF BAFFLE PLATES AND COMBUSTION CHAMBER LINING	48

OPERATIONAL PROBLEMS - TROUBLESHOOTING.....

WARRANTY TERMS

INFORMATION TO ENABLE BETTER REPRODUCTION OF TESTS:.....	52
---	----

TECHNICAL DATA

INSTALLATION

- All local regulations, including those referring to national and European Standards as well as the information provided in this assembly and instruction manual need to be complied with when installing the appliance.
- When you install any kind of fireplace or stove, you must inform the local building and housing authorities. In addition you are obliged to have the installation inspected and approved by a local chimney sweep prior to the commissioning
- To ensure best possible functionality and safety for your installation, we advise you to call a professional fitter. Your Jøtul Dealer will be able to recommend a qualified fitter in your area. For information on Jøtul Dealers, please go to www.jotul.com

SAFETY

Any changed made to the product by the dealer, fitter or user could result in the product and safety functions not functioning as intended. The same applies to the fitting of accessories or extra equipment not supplied by Jøtul AS. This could also be the case if parts that are necessary for the operation and safety of the stove are dismantled or removed.



This stove is produced in accordance with type approval for the product, which also covers the product's Assembly and Instruction Manual. Read and follow the user operating instructions carefully.

The Declaration of Performance (DoP) is available on www.jotul.com

TECHNICAL DATA

Test in compliance with EN 16510		
	Classification of appliance	Type BF
P_{nom}	Nominal heat output	5,0 kW
η_{nom}	Energy efficiency at nominal heat output	76 %
η_s	Seasonal space heating energy efficiency at nominal heat output	66 %
EEI	Energy efficiency index	100
	Energy efficiency class	A
	Fuel	wood logs*
	Fuel length, maximum	300*** mm
	Fuel consumption	1.8 kg/h
	Amount of fuel	1,34 kg
	Amount of fuel, maximum	2 kg
CO_{nom}	CO emission at 13% O ₂ at nominal heat output	0.055 %
		687 mg/Nm ³
NO_{xnom}	NO _x emission at 13% O ₂ at nominal heat output	99 mg/Nm ³
OGC_{nom}	OGC emission at 13% O ₂ at nominal heat output	38 mg/Nm ³
PM_{nom}	Dust emission at 13% O ₂ at nominal heat output	30 mg/Nm ³
p_{nom}	Flue draught at nominal heat output	11 Pa
	Recommended sub-pressure in the connecting piece	18-20 Pa
	Required combustion air supply	17,5 m ³ /h
T_{snom}	Flue gas outlet temperature at nominal heat output	353 °C
T class	Chimney designation	T400 G
$\phi_{fg nom}$	Flue gas mass flow at nominal heat output	6,2 g/sec
V_h	Standing air loss	NPD m ³ /h
	Leakage before testing at gauge pressure of 5 Pa (1013 mbar, 27 °C)	2,3 Nm ³ /h
	Leakage before testing at gauge pressure of 10 Pa (1013 mbar, 27 °C)	3,6 Nm ³ /h
	Leakage before testing at gauge pressure of 15 Pa (1013 mbar, 27 °C)	5,0 Nm ³ /h
CON/INT	Continuous operation (CON)/Intermittent operation (INT)	INT**
	Reaction to fire classification	A1
E, f	Power supply voltage, frequency	5 V

* Use only recommended fuels - designation I.

** Intermittent operation in this context means normal use of a wood-burning stove. In other words, you should let the fire die down until only the embers are left before refueling.

*** The stove can take logs up to 35 cm (vertically placed).


TECHNICAL DATA

Basic technical data F 171 / F 174 / F 176

Materials	Stainless steel Cast iron Ceramic stone/vermiculite Glass
Surface treatment	Senotherm
Smoke outlet	Top / back
d_{out}	Diameter of the flue gas outlet 150 mm
	Fresh air connection piece external diameter 100 mm
L	Overall dimensions (length) 407 mm
H	Overall dimensions (height) 1100/1400/1600 mm
W	Overall dimensions (width) 506 mm
m	Mass (weight) 148 / 169 / 182,7 kg
m_{chim}	Maximum load of a chimney the stove may carry ca. 120 kg

Minimum distances to combustible materials (insulated flue pipe)

d_R	Rear	100/50 mm
d_S	Sides	550 mm
d_C	Ceiling	750 mm
d_P	Front	1000 mm
d_F	Front to the bottom front radiation area	0 mm
d_L	Front to the side front radiation area	0 mm
d_B	Minimum distance below the bottom not regarding feet	0 mm
d_{non}	Minimum distances to non-combustible walls.	50 mm
	Corner	100 mm
	The code for insulated flue pipe	T400-N1-D-Vm-L50050-G100



APPROVAL LABEL

All Jøtul wood-burning stoves are fitted with an approval label that specifies the approval standards and the distance to combustible materials.

The approval label is located at the rear of the stove.

The approval label provides a pin and lot number. These numbers should be quoted when contacting your dealer or Jøtul AS and is required in the event of a complaint.

Approval Label

1	JØTUL F 171 Zensoric JØTUL F 174 Zensoric JØTUL F 176 Zensoric			9
2	Harmonised standard: EN 16510-2-1:2022			
3	Approved by: DTI • NB no. 1235			
4	Classification of appliance: Type BF			
5	Recommended fuels (designation): Wood logs (I)			
6	Manufacturer: Jøtul AS, POB 1411, N-1602 Fredrikstad, Norway			
7	Declaration of Performance: CPR-F170-21052025			
8	Intended use: Space heating in residential buildings			
	P_{nom}	5	kW	10 Read instruction manual for further information
	η_{nom}	76	%	
	CO_{nom} (13 % O ₂)	687	mg/m ³	
	NO_{xnom} (13 % O ₂)	99	mg/m ³	
	OGC_{nom} (13 % O ₂)	38	mg/m ³	
	PM_{nom} (13 % O ₂)	30	mg/m ³	
	p_{nom}	11	Pa	
	d_R (rear)	100	mm	
	d_S (side)	550	mm	
	d_C (ceiling)	750	mm	
	d_P (front)	1000	mm	11 For distance to combustibles when using insulated flue pipe and/or additional accessories, refer to the instruction manual.
	d_F (floor in front)	0	mm	
	d_L (side radiation area)	0	mm	
	d_B (bottom)	0	mm	
	Lot no: 000000 2025 Pin:000			12
	13			

TYPE PLATE EXPLANATION

- 1 Type and/or the model number or designation to enable the appliance to be identified
- 2 Applicable standards
- 3 Name of test centre/certification number
- 4 Classification of appliance
- 5 Recommended fuels
- 6 Manufacturer's name and address
- 7 DOP document number
- 8 Table of values:

P_{nom} - nominal heat output

η_{nom} - energy efficiency at nominal heat output

CO_{nom} - CO emission at 13% O₂ at nominal heat output

NO_{xnom} - NO_x emission at 13 % O₂ at nominal heat output

OGC_{nom} - OGC emission at 13 % O₂ at nominal heat output

PM_{nom} - dust emission at 13 % O₂ at nominal heat output

p_{nom} - flue draught at nominal heat output

Minimum distances to combustible materials:

d_R - back

d_S - sides

d_C - ceiling

d_P - front

d_F - front to the bottom front radiation area

d_L - front to the side front radiation area

d_B - below the bottom (not regarding feet)

- 9 CE mark of conformity- The digits indicate the year of issue of the certificate
- 10 Product specifications and instructions
- 11 Waste electrical and electronic equipment
- 12 Type plate number
- 13 Product registration number

SAFETY

NB: To guarantee optimal performance and safety, Jøtul recommends that its stoves are fitted by a qualified installer (see www.jotul.com for a complete list of dealers).

Any modifications to the product by the distributor, installer or consumer may result in the product and safety features not functioning as intended. The same applies to the installation of accessories or optional extras not supplied by Jøtul. This may also be the case if parts that are essential to the functioning and safety of the fireplace have been disassembled or removed.

In all these cases, the manufacturer is not responsible or liable for the product and the right to make a complaint becomes null and void.

FIRE PREVENTION MEASURES

There is a certain element of danger every time you use your fireplace. The following instructions must therefore be followed:

The minimum safety distances when installing and using the fireplaces are given in the figures on the following pages.

- Ensure that furniture and other combustible materials are not too close to the fireplace. Combustible materials must not be placed within 1000 mm of the fireplace opening.
- Allow the fire to burn out. Never extinguish the flames with water.
- The fireplace becomes hot when lit and may cause burns if touched.
- Only remove ash when the fireplace is cold. Ash can contain hot embers and should therefore be placed in a non-flammable container.
- Ash should be placed outdoors or be emptied in a place where it will not pose a potential fire hazard.

In case of a fire in the chimney:

- Close all openings and valves.
- Keep the door to the firebox closed.
- Call the fire department.
- Ensure that the fireplace and the chimney are inspected and given a green light by a professional before you start to use the fireplace again after an outbreak of fire.

GLOVE

Use the protective glove when handling the product when it is hot.

FLOOR

Foundations

You must make sure that the foundation is suitable for the fireplace. See **“Technical Data”** for specified weight.

We recommend the removal of any flooring that is not attached to the foundation (“floating floors”) beneath the installation.

Requirements for protection of combustible floors under the fireplace

The product has integrated floor protection and can therefore be placed directly on a flammable floor.

Any floor slabs must be in accordance with national laws and regulations. Contact your local building authorities regarding restrictions and installation requirements.

The function of a floor plate is to protect the floor and flammable materials against embers. Jøtul recommends that floor covering made of flammable material, such as linoleum, carpets, etc., be removed from under the floor plate.

Requirements for the protection of flammable floors in front of the fireplace

The floor plate must comply with national laws and regulations.

Contact your local building authorities regarding restrictions and installation requirements.

For Norway: Minimum 300 mm in front of the door and width at least the same as the door.

WALLS

- Place the product in such a way that it is possible to clean the stove, the flue pipe and the chimney passage.
- Ensure that furniture and other combustible materials are not too close to the fireplace.
- Make sure that furniture and other household items are not so close as to get dried up by the stove.

Distance to walls made of combustible material – see the figures on the following pages.

The distances relate to a shielded flue pipe/semi-insulated pipe.

The fireplace can be installed with an uninsulated flue pipe. In this case, the flue pipe must be CE marked and the pipe’s declared distance to flammable materials must be taken into consideration.

Combustible wall protected by firewall

Distance to combustible wall protected by firewall – see the figures on the following pages.

Requirements for firewall

The firewall must be at least 110 mm thick and made of brick, concrete or lightweight concrete. Other materials and structures with satisfactory documentation may also be used, e.g. 50 mm Jøtul Firewall.

Non-flammable materials refer to materials that cannot burn, e.g. bricks, tiles, concrete, mineral wool, various silicate plates, etc. Bear in mind that a short distance to non-flammable walls can result in the drying out and discolouration of paintwork, as well as lead to the formation of cracks.


CEILING

There must be a minimum distance of **750 mm** between the fireplace and a ceiling made of a combustible material above the fireplace.


BALANCED DRAFT CHIMNEY COMPATABILITY

Below you can see 2 different versions of the product. Identify whether the motor is visible or not. If the motor is visible the product is compatible with balanced draft chimney. If the motor is not visible, it is not compatible for balanced chimney draft.

Not compatible with balanced draft chimney




Compatible with balanced draft chimney




INLET FOR BALANCED CHIMNEY

Use the correct inlet when fitting a balanced draft chimney

F 171 Zensoric




F 174, F 176 Zensoric




DIMENSIONS


Jøtul F 171 Zensoric



Jøtul F 174 Zensoric



Jøtul F 176 Zensoric




*Outside air connection $\varnothing 100$ mm

900371-P02


MINIMUM DISTANCES

Placement terms (minimum distances) for:
Jøtul F 171 Zensoric, Jøtul F 174 Zensoric and Jøtul F 176 Zensoric

Combustible wall:



Fire wall:



****With semi-insulated flue pipe down to the top of the stove. The safety distances for the chimney and the flue pipe must be kept!**



Combustible wall:



Firewall:



Eg. 50mm Jøtul Firewall.
110mm refractory brick or material
with similar refractoriness and
insulation properties.



X/Y = According to national laws and regulations

***minimum distance to furniture/combustible material

900371-P02

INSTALLATION

TOOLS FOR ASSEMBLY

- Level
- Pliers
- Crowbar
- 8mm, 10mm & 13mm socket wrench
- 2,5mm, 4mm & 5mm Allen key

LOOSE PARTS

- Glove
- Gasket for flue
- Ring for top cover
- USB-C charging cable for Zensoric control
- Steel brush
- Flue outlet for flue pipe
- Decorative cover for top plate
- 2 pcs. screws M5x10mm for ring
- Kit-folder

ADDITIONAL ACCESSORIES

- Heat accumulating stones (10062576)
- Outside air connection Ø100mm (51012164)

RECYCLING PACKAGING

- A wooden pallet can be reused or cut up and burned in the fireplace or sent for recycling.
- Cardboard packaging should be taken to a local recycling facility.
- Plastic bags should be taken to a local recycling facility.
- Metal straps is delivered for metal recycling.

RECYCLING THE FIREPLACE

- Metal should be taken to a local recycling facility.
- Glass should be disposed of as hazardous waste. The glass in the fireplace must not be placed in a regular source segregation container.
- Burn plates made of vermiculite can be sorted as normal construction waste

- Batteries must be disposed for recycling.
- Electronic components must be disposed of to electronic waste.



ROOM REQUIREMENTS

The stove must be installed in rooms with a good ventilation. A good ventilation is vital for the efficient operation of your stove.

We recommend installing smoke detectors in the home.

The distances specified in the manual only apply if you comply with the maximum amount of firewood. They only guarantee fire safety.

There is no guarantee that the present building materials can withstand the temperature in relation to visual changes.


- Check that Building Regulations and any local by laws are followed during installation.

CHIMNEY AND FLUE PIPE

- The fireplace can be connected to a chimney and flue pipe approved for solid fuel fireplaces with flue gas temperatures as specified in **“Technical Data”**. If a steel chimney is used, this must be marked with T 400 and G for soot fire testing.
- We recommend that the chimney is at least 4 meters high, with a flue diameter between Ø 125 mm and Ø 150 mm, as this will help ensure optimal draft. Please note that smoke leakage or poor performance may occur if the chimney is lower than the recommended height.
- Several solid fuel stoves can be connected to the same chimney system if the chimney cross section is adequate.
- The specified distance to combustible materials applies to this stove.
- Use a CE approved flue pipe and/or steel chimney.
- Take into account the distance from the flue pipe to combustible materials.
- The chimney must be connected in accordance with the installation instructions of the chimney supplier.
- Before a hole is made in the chimney, the fireplace should be test-mounted in order to correctly mark the position of the fireplace and the hole in the chimney. See **“Dimensional diagram and assembly distances”** for your stove for minimum dimensions.
- Use a flue pipe bend with a sweep hatch to allow sweeping.
- Numerous flue bends (and flue bends of many degrees) can affect the draught in the chimney. The same can occur in the case of long horizontal lengths. Please note that it is extremely important for connections to have a degree of flexibility. This is to prevent any movement in the installation leading to the formation of cracks.
- For recommended chimney draught, see **“Technical Data”**. For flue pipe dimensions, see **“Technical Data”**.
- When using a semi-insulated flue pipe (starter section), the part must at a minimum comply with class T 400-N1-D-Vm-L50050-G100. For installation requirements, see drawing.
- The function of the chimney and the flue pipe in terms of safety distances must be met. The chimney shall be proven according to EN 13384-2:2015+A1:2019 depending on the individual situation on site.

NB: The minimum recommended chimney length is 4 m. If the draught is too strong, a flue pipe damper can be installed and used to reduce the draught.

When installing a flue pipe damper, this must be of the type that does not close the flue pipe fully. The damper must be easy to operate, and must have a free opening of at least 20 cm², or 3% of the flue pipe's cross-section if this is larger. The position of the damper must be visible when operating the stove. If a draught regulator is installed, the requirement regarding the free cross-section does not apply, although the unit must be easily accessible for cleaning.



FRESH AIR INTAKE

In a well-insulated house, the air used up by the burning process has to be replaced. This particularly applies to houses with mechanical ventilation. There are different ways of making sure that an air exchange takes place. The most important thing is to ensure that there is a supply of air to the room where the wood stove is located. The external wall vent must be located as close to the wood stove as possible, and you must be able to close it when you are not using the wood stove.

National and local building regulations must be followed with regard to the connection of fresh-air intake.

CLOSED COMBUSTION SYSTEM


You should use the closed combustion system for the wood-burning stove if you live in a newly-built, airtight home.

External combustion air is connected through a ventilation pipe via the wall or floor.

We recommend mounting a valve in the ventilation pipe in order to avoid condensation in the stove and the pipe system, when the stove is not in use. It can also be an advantage to insulate the ventilation pipe.

Minimum Ø 100 mm ventilation pipe, maximum length: 6 metres with a maximum of one bend. We recommend smooth steel pipes.

NOTE: if the stove has a fresh air connection or closed combustion, the ventilation pipe must be open, when the stove is in use!



EXISTING CHIMNEY AND PRE-FABRICATED ELEMENT CHIMNEY

If you intend to connect your stove to an existing chimney, it makes sense to contact an authorised Jøtul dealer, or a local chimney sweep, for advice. These experts will also let you know if your chimney needs renovating.


- When connecting a pre-fabricated element chimney, follow the manufacturer's connection instructions for the relevant chimney type.

CONNECTION BETWEEN STOVE AND STEEL CHIMNEY

Your Jøtul dealer, or local chimney sweep, can advise you on choosing a make and type of steel chimney. This ensures that the chimney will match your wood-burning stove.


REMOVAL OF PACKAGING

- Before installing the fireplace, check it carefully for any signs of damage
- The product is heavy! Ask someone to help you when positioning and installing it. We recommend using a lifting device.



PRIOR TO INSTALLATION

1




2


TIP: Place the knob by the door to keep the door open.



3





4




REMOVAL OF TRANSPORT PROTECTION


- 1** Lift the lower baffle plate, remove transport protection and the pin
- 2** Turn the guide plate 90° and lower it out through the combustion chamber



- 3** Lift the upper baffle plate and remove protection



- 4** Mount again the upper baffle plate with the accompanying pin and the lower baffle plate are fitted afterwards



ZENSORIC SETTINGS

The electronic air control on Jøtul F 170 Zensoric run in 3 levels:

Step 1 - Suitable for softwood, e.g. fir, pine, poplar, willow

Step 2 - Suitable for between hardwoods, e.g. birch, maple, or mixed hardwood

Step 3 - Suitable for hardwood, e.g. beech, ash, oak


The stove is delivered set to Step 2 - which suits the needs of most consumers.

If you want to change the setting, turn the air control button:

Step 1 - Turn counterclockwise - 1 white blink


Step 2 - Set to center position - 2 white blink

Step 3 - Turn clockwise - 3 white blink




BATTERY CHARGING

Before firing in the stove, the electronic air control- Zensoric must be charged by connecting the supplied USB-C charger plug at the bottom of the stove and the 5V power supply in the socket.



PRIOR TO INSTALLATION


Make sure the diode is in place as shown below.




HEIGHT ADJUSTMENT OF WOOD STOVE

The stove has four adjustment screws under the stove. Use the adjustment screws to get the stove to stand straight and level.

NOTICE: It is very important that the stove is level to allow an optimal function of the door. Please note that once mounted the stove can no longer be adjusted!



DOOR (SELF CLOSING)




The oven door is supplied with a self-closing function.

If you do not want self-closing, loosen the pinion screw by turning the screw counter-clockwise with an Allen key (2.5 mm)

If it is necessary to tighten the self-closing spring, see page 44 for activation of self-closing.

If you have a top outlet, the side panel must first be removed. See page 35 under Maintenance for dismantling the side panel.

CLOSING THE DOOR




NOTICE: It is very important that the door closes tightly to the stove to prevent soot on the glass.


The stove has to be fired a couple of times, before the gasket “settles”. Therefore, give the door a push on the handle so that it hits the screw in the side.

SMOKE OUTLET REAR EXIT


1




2




3




4




5




6




7




8



9





10




JØTUL F 176 ZENSORIC (HIGH TOP) ASSEMBLY

1




2




3

Be sure to adjust the High Top until it is positioned correctly in relation to the rest of the product.



4



Then screw the product into place.

HEAT ACCUMULATING STONE (ACCESSORIES)

Heat-accumulating stone is possible for:

Jøtul F 171 Zensoric 1100 mm. (2 pcs. approx. 21 kg)

Jøtul F 174 Zensoric 1400 mm. (2 pcs. approx. 21 kg)





Jøtul F 176 Zensoric 1600 mm. (5 pcs. approx. 52.5 kg)

Heat-accumulating stone is made of a special material with high heat capacity. The stones are heated during firing and emits heat again after the end of firing. This extends the time the oven is hot.



FLOOR PLATE (ACCESSORIES)

Push the floor plate close to the oven as shown in the picture.



INSTRUCTION FOR USE

CB-TECHNOLOGY (CLEAN BURN)

The stove is equipped with CB technology. In order to ensure optimal combustion of gases released during the combustion process, air passes through a specially developed system of channels. The heated air is conducted into the combustion chamber through the holes in the rear lining of the combustion chamber and at the baffle plates. This airflow is controlled by the rate of combustion and cannot therefore be regulated.

NOTE: The wood must never be placed higher than the lower tertiary holes at the rear of the burn chamber (This does not apply at a cold start).

ELECTRONIC AIR CONTROL

The stove is equipped with an electronic air control- Zensoric, which self-regulates the combustion of the wood with the right amount of air and the right temperature. Zensoric is designed to achieve the cleanest possible combustion, which can be difficult to achieve with manual operation.

Zensoric is battery powered and keeps charging for up to an entire firing season. It is recommended to charge Zensoric when the firing season is over. Charging is done by connecting the supplied USB-C charger plug at the bottom of the side of the stove and the 5V power supply in the socket. It is not recommended to charge during firing.

When opening the stove door (when it is cold), the stove gives off signal status- see "Zensoric Signal Guide" - page 29.

MANUAL AIR CONTROL

In addition to the automatic control, which the control itself performs, you can control the combustion / flames up or down with the air control button under the door.

With low draft in the chimney, the air regulation can be set to 100 % when lighting.

Settings for normal load: 25-75%

BAFFLE PLATES

The baffle plates are located in the upper part of the combustion chamber. The plates hold back smoke, making sure it stays inside the combustion chamber for a longer time before escaping through the chimney. This reduces the flue gas temperature as the gases have more time to dissipate heat to the stove.

The baffle plates must be removed for sweeping; see "Maintenance". Note that the baffle plates are made of porous, ceramic material, and is liable to break easily. You should therefore handle them with care.


The baffle plates are subject to wear and tear and not covered by the warrant

ASH CONTAINER

Open the door and the grate in the bottom of the stove and lift out the ash container.

The ash container can be warm. Wear a glove when handling the stove.

- To achieve optimal combustion, do not overfill the ash container. It should therefore be emptied when it is 3/4 full
- Never empty ashes into a flammable container. Ashes can contain glowing embers long after you finish operating the stove
- Keep the ash container closed except during ignition, refuelling and removal of residue material to prevent fume spillage.



INSTRUCTIONS FOR USE

ZENSORIC SIGNAL GUIDE

- 1 green blink = air damper test OK
- 1 green blink repeated every 8 seconds = add wood to achieve best possible combustion results
- 2 blue blink repeated every 8 seconds = recharge battery
- 1 red blink = air damper fault
- 2 red blink = battery level low, Zensoric switches off
- 3 red blink = temperature gauge fault (See page 44 for replacing temperature gauge)


When charging:

Continuous red = charging

LED goes out = fully charged

No blinking at first opening of cold stove = fault on door sensor (see page: 46 for switching the door sensor)

In case of error - contact the dealer of the stove





RESET ZENSORIC

The reset function is done by connecting the supplied USB-C charger plug at the bottom of the side of the stove and the 5V power supply in the socket.

Next, unplug after 30 sec. and open the door and the Zensoric resets

SETTINGS FOR NORMAL LOAD: 25% - 75%



DAILY USE

ODOURS WHEN USING THE FIREPLACE FOR THE FIRST TIME

When the fireplace is used for the first time, it may give off a slight smell. This is because the paint on the outside is drying. You should open some windows to ensure the room is ventilated.

“TOP DOWN” LIGHTING THE FIRE

Lighting the fire from the top down provides more environmentally friendly lighting and helps to keep the glass areas as clean as possible. The flames work their way down. Lighting from the top produces faster heating of the burn chamber, ensuring that you quickly achieve a good draught in the stovepipe and pipe, more oxygen for the flames and a higher temperature.

- 4 logs measuring approx. 20-23 cm in length and weighing approx. 0.3-0.5 kg each
 - 10-12 kindling sticks measuring approx. 20 cm and with a combined weight of approx. 0.3-0,5 kg
 - 3 firelighter sachets/cubes
1. Place the pieces of wood, firewood and fire lighters in the combustion chamber as shown below
 2. Set the combustion air control to maximum for 15 minutes (See “Instructions for use”)
 3. When the large pieces of wood have caught fire, you can adjust the combustion air to the desired level

NOTE: Never add so much wood that it covers the tertiary holes (This does not apply when starting from cold).



ADDING FIREWOOD

Stoke the stove frequently but only add small amounts of fuel at a time. If the stove is filled too full, the heat created may cause extreme stress in the chimney. Add fuel to the fire in moderation. Avoid smouldering fires as this produces the most pollution. The fire is best when it is burning well and the smoke from the chimney is almost invisible. To achieve the cleanest possible combustion and best effect, add wood when the green signal is repeated every 8 seconds as described in the Zensoric Signal Guide table on the previous page.

HEATING ADVICE

NB: Logs that have been stored outdoors or in a cold room should be brought indoors approx. 24 hours before use to bring them up to room temperature.

There are various ways of heating the stove, but it is always important to be careful about what you put in the stove. See the section on **“Wood quality”**.

NB: Burning with a poor air supply can cause insufficient combustion, reduced energy efficiency and increased emissions of particles, black carbon and other compounds that are harmful to health and the environment.

Wood quality

By quality wood we mean most well-known types of wood such as birch, spruce and pine.

The logs should be dried so that the moisture content is no more than 20%.

To achieve this, the logs should be cut no later than in late winter. They should be split and stacked in a way that ensures good ventilation. The wood stacks should be covered to protect the logs from rain. The logs should be brought indoors during early autumn and stacked/stored for use in the coming winter.

Be especially careful never to use the following materials as fuel in your fireplace:

- Household rubbish, plastic bags, etc.
- Painted or impregnated timber (which is extremely toxic).
- Laminated wooden planks.
- Driftwood
- These may harm the stove and are also pollutants.

Never use petrol, paraffin, methylated spirit or similar liquids to light the fire. You may cause serious injury to yourself and damage to the product.

WARNING AGAINST OVERHEATING

Never overstoke the fireplace!

Overheating occurs when there is too much fuel and/or too much air so that too much heat develops. A sure sign of overheating is when parts of the stove glow red. If this happens, reduce the air vent opening immediately.

Seek professional advice if you suspect that the chimney is not drawing properly (too much/too little draught). (For further information, see “Installation” (Chimney and flue pipe).)

REMOVING ASH

- Only remove ash when the fireplace is cold.
- Use a scoop or similar and scrape out the ash.
- Ash should be placed outdoors or be emptied in a place where it will not pose a potential fire hazard.

OPERATION UNDER DIFFERENT WEATHER CONDITIONS

The performance of the stove can be affected considerably by the wind acting on the chimney at different strengths. It may therefore be necessary to adjust the air supply to ensure good combustion performance. It might also be a good idea to install a damper in the flue pipe so that the chimney draught can be regulated according to the strength of the wind.

Fog and mist can have a significant impact on the chimney draught and it might be necessary to use other combustion air settings to ensure good performance.

CONDENSATION

Condensation from the fireplace/flue pipe/chimney may occur. This may well be related to damp fuel or temperature differences between the fireplace and the surrounding area. Condensation that comes from the fireplace has the appearance of a black, tar-like liquid. This should be wiped off immediately to avoid discolouration of the fireplace, floor and surrounding building components.

Rapid lighting and fresh stoking reduce the risk of condensation.

If the condensation persists, mineral sand can be used on the fireplace's bottom plate.

THE CHIMNEY'S FUNCTION

The chimney is the engine of the wood stove and is crucial for its functioning. Chimney drafts create negative pressure in wood stoves. This negative pressure removes the smoke from the stove and sucks the air through the combustion air vent for the burning process.

The draught in the chimney is caused by the difference in temperatures inside and outside the chimney. The greater the temperature difference, the better the draught in the chimney. It is therefore important to allow the chimney to reach operating temperature before adjusting the damper settings to restrict combustion in the stove (a brickwork chimney takes longer to reach operating temperature than a steel chimney).

It is particularly important to reach operating temperature as quickly as possible on days on which the draught in the chimney is poor due to unfavourable wind and weather conditions. It is important to achieve some flames quickly. Chop the wood into much smaller pieces and use an extra firelighter.

If the stove has not been used for some considerable time, it is important to check the chimney pipe for blockage.

It is possible to connect several solid fuel stoves to the same chimney. However, it is important to check out the applicable rules in this areas first.

Even a good chimney can function poorly if it is used incorrectly. Correspondingly, a poor chimney can function well if it is used correctly.

GENERAL NOTES

PLEASE NOTE! Parts of the wood-burning stove, especially the outer surfaces, become hot during use. Due care should be exercised.

- Wear a glove when handling the stove
- Never empty ashes into a flammable container. Ashes can contain glowing embers long after you finish operating the stove
- Keep the combustion chamber closed except during ignition, refuelling and removal of residue material to prevent fume spillage
- Keep the air intake and output holes free from any accidental blockage while the stove is in use
- When the stove is not in use you can close the dampers to avoid a draught through the stove
- If the stove has not been used for some time, you should check the flue passageways for potential blockages before relighting
- We advise you strongly not to use the stove over night. The stove is not suited for this purpose
- NOTE: Never place flammable material in the radiation zone of the stove!

MAINTENANCE

CLEANING THE GLASS

Jøtul's fireplaces are fitted with air washing of the glass. Via the air vent, air is deflected down along the inside of the glass, reducing the accumulation of soot deposits.

There will always be some soot on the glass, however, but the amount depends on the local conditions and the adjustment of the air vent. Most of the soot layer will normally be burned off when the air vent is fully opened and the fire is burning briskly.




Good advice! Normal cleaning – take a piece of kitchen paper and dampen it with warm water. Dab it on some ash from the burn chamber then rub the glass with the paper. Wipe clean with fresh water. Dry well. If the glass needs cleaning more thoroughly, use a detergent for glass (follow the manufacturer's instructions on the bottle).

CLEANING AND REMOVING SOOT

Soot deposits may build up on the internal surfaces of the fireplace during use. Soot is a good insulator and will therefore reduce the fireplace's heat output. If soot deposits accumulate when using the product, they can easily be removed by using a soot remover.

In order to prevent a layer of water and tar from forming in the fireplace, you should regularly allow the fire to burn hot in order to remove the layer. Your product should be cleaned internally once a year to ensure the best heating effect. It is a good idea to do this when cleaning the chimney and flue pipes.

The oven comes with a steel broom that can be used to clean the oven. If necessary, the tool can be bent to reach the most difficult places. Remove the vault and burner plates before cleaning the wood stove and sweeping the flue and chimney. (See "Removal of baffle plates and combustion chamber lining")



SWEEPING THE FLUE PIPE TO THE CHIMNEY

Flue pipes must be swept through the flue pipe sweeping hatch or through the door opening. The baffle and exhaust deflector must be removed first.

CHECKING THE FIREPLACE

Jøtul recommends that you carefully inspect your fireplace yourself after it has been swept/cleaned. Check all visible surfaces for cracks. Also check that all joints are sealed and that the gaskets are in the correct position. Any gaskets showing signs of wear or deformation must be replaced.

Thoroughly clean the gasket grooves, apply ceramic glue (available from your local Jøtul dealer) and press the gasket well into place. The joint will dry quickly.

EXTERNAL MAINTENANCE

Painted products may change colour after they have been used for several years. The surface should be cleaned and brushed free of any loose particles before new paint is applied.

NB: Do not place anything on the stove's top plate, as this could result in permanent damage to the paintwork.

SIDE PANEL DISASSEMBLY

We recommend that there are 2 people when dismantling the side panel.


The side panel must be dismantled if you are going to:

- Activate door self-closing if you have deactivated it (Side panel A)
- Changing the temperature gauge (Side panel B)
- Replacing the door sensor (Side panel B)

The instructions below show how to remove the side panel (A). When replacing the temperature gauge or door sensor, the side panel (B) must be dismantled. Use the same procedure as side panel (A) only on the opposite side.

With a top outlet and/or with heat-accumulating stones, accessibility will be reduced. Remove the side panels to access the areas you need.

If you have a rear outlet, you will be able to change the temperature gauge and activate self-closing without removing the side panel.




TOOLS

- 13mm socket wrench
- 5mm and 2.5mm Allen wrench


SIDE PANEL DISASSEMBLY

1

13mm socket wrench




2





SIDE PANEL DISASSEMBLY

3




4


Be careful! Preferably 2 people when separating the side panel. The side panel must be held in place while the screws are screwed in and out.



5




6




SIDE PANEL ASSEMBLY

1





2



SIDE PANEL ASSEMBLY

3


Make sure the side panel fits correctly on the step shown below.




SIDE PANEL ASSEMBLY

4

Be careful! Preferably 2 people should disassemble the side panel. The side panel should be held in place while screwing in and out the screws.




5




SIDE PANEL ASSEMBLY

6



7

Make sure the side panel fits correctly by comparing the lines on the adjacent cast iron parts.




ENABLE SELF-CLOSING DOOR

Tighten the spring by turning the long screw (inside the spring (A)) counter-clockwise with an Allen key (5 mm). While tightening the spring, tighten the lower pinion screw (B) tightly clockwise with an Allen key (2.5 mm)


TOOLS

- 5mm Allen key
- 2,5mm Allen key




DISASSEMBLY TEMPERATURE GAUGE

- 1 To get more space to work in, you can LOOSEN the nut slightly as shown in the picture below and push the back cover out.




DISASSEMBLY TEMPERATURE GAUGE

2




3

4mm Allen key




ASSEMBLY TEMPERATURE GAUGE

1




2




DISASSEMBLY DOOR SENSOR


1




2



1




2




REMOVAL OF BAFFLE PLATES AND COMBUSTION CHAMBER LINING


Show caution when removing the baffle plates from the stove.



1




2




REMOVAL OF BAFFLE PLATES AND COMBUSTION CHAMBER LINING



3



4



5



OPERATIONAL PROBLEMS - TROUBLESHOOTING

POOR DRAUGHT

Check that the length of the chimney complies with national legislation and regulatory requirements. (For further information, see section “Technical Data” and “Installation” (Chimney and flue pipe).)

Check that the minimum cross-section of the chimney is in accordance with the specification in “Technical Data” in the Installation Manual.

Make sure that there is nothing preventing the smoke from escaping: branches, trees, etc.

Seek professional advice and help if you suspect that the chimney is not drawing properly (too much/too little draught).

THE FIRE DIES OUT AFTER A WHILE

- Make sure that the fuel is dry enough.
- Check whether there is negative pressure in the house. Turn off fans and open a window close to the stove.
- Make sure the air vent is open.
- Make sure the smoke outlet is not clogged with soot.

IF THERE IS EXCESSIVE SOOT ON THE GLASS

There will always be some soot on the glass, but the amount depends on:

- How dry the fuel is.
- The local draught conditions.
- Adjustment of the air vent.

Most of the soot layer will normally be burned off when the air vent is fully opened and the fire is burning briskly

WARRANTY TERMS

OUR WARRANTY COVERS:

Jøtul AS guarantees that the external cast iron parts are free from material defects or production faults at the time of purchase. The warranty is valid for 5 years from the date of delivery. You can extend the warranty for external cast-iron parts to 25 years from the date of delivery by registering the product on jotul.com, and by printing the extended warranty card, within three months of the purchase. We recommend that you store the warranty card together with your receipt. Jøtul AS also guarantees that steel components are free from material defects or production faults at the time of purchase, for a period of 5 years from the delivery date.

The warranty applies on condition that the stove has been installed by a qualified fitter in accordance with the applicable laws and regulations, and that Jøtul's installation and operating instructions are followed. Repaired products or replacement elements are guaranteed within the original warranty period.

Jøtul warrants that the electronic components in Jøtul wood stoves are free from defects in materials or manufacturing for a period of two (2) years from the date of purchase.

THE WARRANTY DOES NOT COVER:

- Damage to consumables such as burn plates, inner bottoms, smoke baffles, gaskets, etc., which are damaged over time by normal wear and tear.
- Damage resulting from inadequate maintenance, overheating, the use of unsuitable fuel (examples of unsuitable fuel include, but are not limited to, driftwood, impregnated wood, plank offcuts, chipboard) or wood that is too damp/wet.
- The installation of optional extras with the aim of rectifying local draught conditions, air supply or other circumstances beyond Jøtul's control.
- Alterations/modifications to the fireplace without Jøtul's consent or the use of non-original parts.
- Damage caused during storage at a distributor, transport from a distributor or during installation.
- Products that are sold by unauthorised dealers in areas where Jøtul operates with a selective distribution system.
- Associated costs (examples include, but are not limited to, transport, labour, travel) or indirect damage.

For pellet ovens, glass, stone, concrete, enamel and paint (examples include, but are not limited to, chipping, cracks, bubbles or discolouration and crazing), the right to make a complaint applies. This warranty is valid for purchases made within the European Economic Area (EEA). All warranty claims must be submitted to the authorised Jøtul dealer within a reasonable amount of time, and no later than 14 days from the time when the fault or deficiency was first discovered. See the list of importers and dealers on our website: www.jotul.com/no/forhandlere/finn-forhandler.

If Jøtul is not in a position to fulfil the obligations outlined in the above warranty terms, Jøtul will offer a replacement product with a similar heating capacity free of charge.

Jøtul reserves the right to reject the replacement of parts or services if the warranty has not been registered online. The warranty does not affect any rights in relation to the applicable right to make a complaint. The warranty applies from the date of purchase, and only against a receipt/serial number.

INFORMATION TO ENABLE BETTER REPRODUCTION OF TESTS:

Refueling Criteria at ITT: Mass measured by the platform scale.

Initial Fire Bed: 520 grams at the start of the test.

Average CO₂ Value at Refueling: 4.5%.

Increment of Basic Fire Bed (BFB) Between Refuelings: 10 grams

Stove Settings:

The stove is equipped with Automated Combustion Air Controls (ACC). It was set to operate autonomously with a basic setting of:
1/3 automatic
2/3 manual
25% overall setting.

Parameter	Value			Metric	Threshold
Ambient	27				
Barometric pressure	1013				
Test pressure	5	10	15	Pa	-
Leak rate, before the test	2,3	3,6	5,0	Nm³/h	-
Leak rate re-calculated to 10 Pa	N/A				3,0
Product of leak rate x CO emi	N/A				<2400

Wood Specifications:

Total of 1.33 kg birch wood. Distributed among three wood logs, each 22 cm long. Combined mass of 1.33 kg.

Two major wood logs placed at the bottom, parallel to the loading door.





Jøtul continuously strives to improve its products and reserves the right to modify specifications, colours and fittings without prior notice.

Quality

Our quality policy should provide our customers with the security and quality experience that Jøtul has stood for ever since the business was founded in 1853.